

KES

Keep Efficient Simple



Keep Efficient Simple

SHOWER SYSTEM INSTALLATION GUIDE

Model
XB6202
Series

CUSTOMER SERVICES

cs@keshome.com




CHAT NOW

XB6202.V1.1


Table of Contents

| | |
|--|----|
| Pack List | 01 |
| Illustrated Parts | 02 |
| After-sale Service..... | 04 |
| Notes Before Installation..... | 05 |
| Important Dimensions..... | 07 |
| Rough-in Installation..... | 08 |
| Handle Installation and Operation..... | 13 |
| Leakage Check..... | 14 |
| Temperature Check..... | 16 |
| Plaster Ground Installation..... | 18 |
| Shower Trim Installation..... | 19 |
| For Copper Installation..... | 23 |
| Low Pressure / Slow Flow?..... | 25 |
| Water not hot enough?..... | 26 |
| Troubleshooting..... | 31 |
| Care Instructions..... | 36 |
| Lifetime Limited Warranty..... | 38 |


Pack List




1 Rain Showerhead



2 Rough-in Valve




3 Plaster Ground



4 Escutcheon

















5 Handle



6 Shower Arm & Flange

7 Hardware


| | | | | | | |
|-----------------|---|---|---|---|---|---|
| Rough-in Kit |  |  |  |  |  |  |
| | x4 | x2 | x4 | x1 | x4 | x1 |
| Shower Trim Kit |  |  |  | | | |
| | x1 | x1 | x1 | | | |
| Spare Kit |  |  |  |  |  | |
| | x1 | x1 | x3 | x2 | x1 | |

Parts Missing/Damaged?




Contact us
 Replace for FREE
cs@keshome.com

Illustrated Parts



Illustrated Parts



After-sale Service



24-Hour Customer Support

Visit our customer support center at www.keshome.com/cs, available 24/7.

Contact us via Amazon Message, instant chat, and email during business hours.



Free Replacement Parts

Please contact us if any parts are damaged or missing. Parts provided free. (Shipping fees may apply)



1-on-1 Responsive Customer Service

No need to restate your case with each contact. Our dedicated team of professionals will work on resolving your issue until it is resolved.



Parts Customization

No need to worry about unexpected challenges. Share your requirements, and we'll customize parts to meet your specific needs.



Return Policy

Feel free to return within 30 days. Please ensure all items (particularly the hardware pack) are in the box before returning.

Missing Return Window?

No Worry!
We totally understand



Contact us
Replace for FREE

Notes Before Installation

RECOMMENDED TOOLS



PEX

Tools



Matching Parts



COPPER

Tools



Matching Parts



PVC/CPVC

Tools



Matching Parts



Notes Before Installation

Working Conditions

Environment Temperature: 5 - 48.9°C (41 - 120°F)

Inlet Water Temperature: 5 - 70°C (41 - 158°F)

Water Pressure: 0.14 - 0.55 MPa


Plumbing Connection: 1/2"-14 NPT

Notes Before Installation

Read all instructions before installation and follow this manual to install this product.

- Wear gloves during installation. DO NOT use hard or sharp tools such as a wrench to touch the coated product surfaces directly, or it may cause scratches and damage.
- The product is NOT designed for outdoor use.
- This product must be installed, flushed, and tested in accordance with all state and local plumbing and building codes. Call a professional if you are uncertain about installing this product properly.
- The product may only be used for bathing, hygienic, and body cleaning purposes.
- Choking hazard. Please keep all small parts and plastic bags out of the reach of children.

Important Dimensions



1/2"-14 NPT
Thread Length:
15/16"

1/2"-14 NPT

80" - 86"

39" - 59"

Height Recommendations:





Showerhead: 82"

Rough-in Valve: 42"



Rough-in Installation

The following installation method is shown as PEX.



For copper installation illustrations, please refer to page 23.





Rough-in Installation





Rough-in Installation






Rough-in Installation




Rough-in Installation



Handle Installation and Operation





Leakage Check





2

Turn on **BOTH** hot and cold water supplies.


Leakage Check





Temperature Check






Temperature Check







Plaster Ground Installation







Shower Trim Installation



Shower Trim Installation




Shower Trim Installation






Shower Trim Installation


13




For Copper Installation







For Copper Installation



Low Pressure / Slow Flow? Check and clean flow restrictor!



Showerhead





Water not hot enough?




Make sure your hot water temperature $\geq 120^{\circ}\text{F}(48.9^{\circ}\text{C})$
Recommend: 120 - 140 $^{\circ}\text{F}$ (48.9 - 60 $^{\circ}\text{C}$)

1 Still NOT hot enough?
Turn off both hot and cold water supplies.



Water not hot enough?

4



Hotter Colder


Warning: Temperature change per tooth (notch) could be 1.8 - 7.5°F (1 - 4°C) base on inlet water conditions.
Repeat as necessary.

If the temperature limit stop has reached the limit, please contact us.





Replace for FREE
cs@keshome.com
chat now

Water not hot enough?



6 Turn on **BOTH** hot and cold water supplies.



Water not hot enough?

Warning

Setting the Adjustable Temperature Limit Stop in The Last Position or beyond The Last Position (counterclockwise) could result in scald injury. It is vital to adjust the Adjustable Temperature Limit Stop to avoid scald injury to the user when the handle of the valve is rotated to the hot side. Please check your local plumbing codes for maximum water mix temperature (normally should not exceed 120°F). If inlet water temperature changes seasonally, you may need to readjust the Adjustable Temperature Limit Stop. Recommended water temperature for bath or shower is between 90 - 110°F. Run the water so that the cold water is as cold as it will get and hot water is as hot as it will get. Place the handle on the cartridge stem and rotate the handle clockwise until the handle stops. Place a thermometer in a plastic tumbler and hold in the water stream. If the water temperature is above 120°F or the maximum temperature requirement of local plumbing codes (whichever is lower), the Rotational Limit Stop must be readjusted clockwise to decrease outlet water temperature.

MAKE SURE COLD WATER FLOWS FROM THE VALVE FIRST. MAKE SURE WATER FLOWING FROM THE VALVE AT THE HOTTEST FLOW POSSIBLE DOES NOT EXCEED 120°F OR THE MAXIMUM ALLOWED BY YOUR LOCAL PLUMBING CODES.

Caution

This system/device has to be set by the installer to ensure safe, maximum temperature. Any variation in the setting may raise the discharge temperature above the limit considered safe and may cause hot water burns.

Warning

This pressure balance valve does not control temperature, only pressure fluctuations. The Limit Stop does not control temperature variations caused by inlet temperature variations.

Pressure balance valve will not provide protection from hot water burns when there is a failure of other temperature controlling devices elsewhere in the plumbing system. And if the Adjustable Temperature Limit Stop is not set properly, the hot water temperature is changed after the Adjustable Temperature Limit Stop is set, or if the water inlet temperature changes due to seasonal variations, it also may cause hot water burns.


Water not hot enough?

Notice to the installer Caution!

As the installer of this valve, it is your duty to INSTALL and ADJUST this valve properly according to the instructions given. This valve does not adjust automatically for inlet temperature changes, further adjustments maybe necessary due to seasonal water temperature change.

YOU MUST inform the owner/user of this requirement by following the instructions. After installation and adjustment, you must affix your name, company name and the date you adjusted the Adjustable Temperature Limit Stop to a label and apply or attach the label to the backside of the closet cabinet door and a warning label to the hot water heater. Leave this instruction sheet for the owner's/user's reference.


Troubleshooting

| Fault | Cause | Remedy |
|---|-------------------------|---|
| Parts missing/damaged Miss return window | | |
| Need spare parts/ customized parts | | Contact KES |
| Connection/thread problems | | |
| Scratched surfaces | |  |
| Unable to install handle | Rough-in valve too deep | Chat now! |
| Shower arm thread too short | Ear drop too deep | cs@keshome.com |
| Decorative flange too small | Tile opening too large | |
| Backflow preventer damaged | | Use spare backflow preventers |

Leakage

Valve bonnet nut loose


Tighten bonnet nut
Scan for video guide




From faucet valve

Incorrect valve installation


Align valve bottom with main body, then reinstall it





Troubleshooting

| Leakage | | |
|-------------------------|---|--|
| From faucet valve | Valve damaged | Contact KES |
| From connectors | Wrong size or damaged plumbing fittings | Double check connectors or contact KES |
| | Insufficient Teflon tape/sealant | Wrap Teflon tape around connector 5 times and apply sealant |
| From shower head | Shower head damaged/cracked | Contact KES with photo/ video for replacement |
| | Ball joint adapter loosed | |
| | White rubber ring worn | |
| | Filter gasket missed | Use spare filter gasket |
| | |  |
| Dripping after shut-off | Valve fouled with debris | Remove and clean the valve |
| | Valve damaged | Contact KES |

Troubleshooting

| No or Low Flow | |
|----------------------|--|
| | <p>Low inlet water pressure</p> <p>Check water pressure (If a pump has been installed, check to see if it is working)</p> |
| | <p>Nozzles clogged</p> <p>Wipe clogged nozzles several times with fingers while the water is running</p> |
| | <p>Filter gasket in showerhead connector clogged</p> <p>Remove and clean the filter gasket, then reinstall it</p> |
| No or low water flow | <p>Restrictors clogged</p> <p>Check and clean flow restrictor See page 25 Scan for video guide</p> <div style="text-align: center;">  </div> |
| | <p>Valve clogged</p> <p>Remove and clean the valve</p> |
| | <p>Either hot or cold water supply is low, causing low mixed flow since pressure balance valve always keeps both supply sides at equal pressure</p> <p>Make sure both hot and cold supplies are at full volume and especially, the heater provides enough flow</p> |

Troubleshooting

| Others | | |
|-------------------------|---|---|
| Water not hot enough | Heater temperature set too low | Turn up the heater temperature |
| | Temperature limited stop restriction | Adjust the temperature limit stop See page 26 Scan for video guide  |
| Pipe noise | Plumbing not properly secured | Contact a professional to check |
| | Valve/Backflow Preventer damaged | Contact KES |
| Limescale build-up | Hard water | Use scale remover |
| Finish peeled off/faded | Wear and tear Limescale build-up Improper maintenance | DO NOT use corrosive cleaners Follow proper cleaning instructions Scan for video guide  |
| Parts rusted | | |

Troubleshooting

| Others | | |
|-----------------------------------|---|--|
| Product certification /compliance | Complies with *ASME A112.18.1/ CSA B125.1 standards of cUPC certified by IAPMO *California Energy Commission (CEC) regulations | Certificates Hyperlink: cUPC: https://plm.iapmo.org/pld#/certificate/10664/2509 CEC: https://cacertappliances.energy.ca.gov/Pages/ApplianceSearch.aspx |

If your problem still exists or is not covered above, contact KES



cs@keshome.com


Care Instructions

To keep the product looking new, please follow these simple care instructions:


DO:

- Daily Maintenance


Showerhead



Handshower





Finish




- Descaling Treatment

To effectively remove limescale buildup caused by hard water, follow these steps:



Care Instructions



For best results, perform this descaling treatment every one to three months. Regular maintenance will help keep the product looking its best for years.

Note:

Test scale remover in an inconspicuous area of the product finish before using it widely to check for compatibility.

DO NOT:

- Do not use cleaning products with acidic, caustic, bleach, or mildly alkaline properties and those labeled as rust removers.
- Do not use cleaning materials or appliances with an abrasive effect, such as unsuitable cleaning powders, sponge pads or microfiber cloths.

Failure to follow these care instructions may damage the product finish.

Lifetime Limited Warranty

Faucets

KES warrants its faucets purchased from authorized sellers to be leak and drip free as long as the original consumer owns their home in which the product was first installed (the "Warranty Period" for homeowners). For all other purchasers (including purchasers for industrial, commercial and business use) are warranted for a period of 3 years from the original date of purchase (the "Warranty Period" for non-homeowners).

Other Products

Products other than faucets are backed by a 1-Year Limited Manufacturer's Warranty (the "Warranty Period" for non-faucet products).

What We Will Do

If a faucet should ever develop a leak or drip during the Warranty Period, KES will FREE OF CHARGE provide the parts necessary to put the faucet back in good working condition.

For non-faucet products, KES will replace FREE OF CHARGE any part that proves defective in material and manufacturing workmanship during the Warranty Period.

If repair or replacement is not practical, KES may elect to refund the purchase price in exchange for the return of the product.

What Is Not Covered

KES shall not be liable for any damage to the product resulting from reasonable wear and tear, installation and maintenance errors, outdoor use, freezing water, abuse, misuse, and use of cleaners containing abrasive cleansers, ammonia, bleach, acids, waxes, alcohol or other organic solvents.

KES is not responsible for removal, installation, labor charges, or other incidental or consequential costs. In no event shall the liability of KES exceed the purchase price of the product.

Lifetime Limited Warranty

KES AND/OR SELLER ARE PROVIDING THESE WARRANTIES IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KES AND/OR SELLER DISCLAIM ALL LIABILITY FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction.

This warranty applies only to KES products sold in North America and Europe.

Contact KES

Email: cs@keshome.com

Online Contact:



Please provide:

- dated proof of purchase
- description of the defect/fault
- picture or video showing the issue(s) (optional)